


INSTRUCTIONS DC102: Small Animation Card

PART 1

Die cut front of the card using main die cut and fold on scoring line



glue animation grid onto the grid arms. Make sure the grid is straight.



PART 2

Use a 5 3/4" x 4" in page and fold in half




Align part 2 with part 1
Die cut window. Make sure to use part 2 as reference to center window opening



PART 3

Use main die cut for the back of the card. Cut off the 2 grid arms and fold



Glue folded lip on the opening back of part 2



ASSEMBLE ANIMATION CARD



=

